



## PATTERN COLLECTIONS

Discover the artistry and elegance of our decal decoration tableware collection. Thoughtfully designed to bring a touch of sophistication and style to your dining experience.

|    |                       |            |
|----|-----------------------|------------|
| 01 | Artist Blue           | M363, N002 |
| 02 | Band of Gold          | 2730       |
| 03 | Band of Platinum      | 2738       |
| 04 | Canyon                | M965       |
| 05 | Chloe                 | M873       |
| 05 | Floral Blue & White   | M740       |
| 07 | Florentina Cream Gold | BD9E       |
| 08 | Foliage               | M996       |
| 09 | Gracious              | N001       |
| 10 | Havana Blue           | 816A       |
| 11 | Nancy                 | M392       |
| 12 | Vida                  | M874       |
| 13 | Wood Thai             | BM7A, B    |

# M363, N002 ARTIST BLUE

ITEM RANGE



## COUPE PLATE



1410127 Coupe Plate 27 cm.



1410123 Coupe Plate 23 cm.



## SOUP PLATE

1381223 Soup Plate 23 cm. (800 cc.)



## BOWL

1061323 Vegetable Bowl 23 cm. (700 cc.)



## MUG

1382411 Mug 360cc.

PATRA



# 2730 BAND OF GOLD

## ITEM RANGE

PATRA



### Plate

1061027 Plate 27 cm.



### Plate

1061023 Plate 23 cm.  
1061020 Plate 20.5 cm.  
1061016 Plate 16 cm.



### Soup Plate

1061223 Soup Plate 23 cm.



### Oval Plate

1064086 Oval Plate 36 cm.  
1064078 Oval Plate 28 cm.  
1064073 Oval Plate 23 cm.



### Deep Bowl

1023067 Deep Bowl 17.5 cm.  
1023070 Deep Bowl 20 cm.



### Soup Bowl

1023012 Noodle Bowl 12 cm.  
1023011 Rice Bowl 11.5 cm.  
1023009 Shark's Fin Soup Bowl 9.5 cm.



### Tea Cup & Saucer 1072057

1072055 Tea Cup 200 cc.  
1072006 Saucer 15 cm.



### Tea Pot with Lid 1076032

1076030 Tea Pot 800 cc.Body  
1076031 Tea Pot Lid

### Sugar Set 1076178

1076176 Sugar 250 cc.Body  
1076177 Sugar Lid

### Creamer

1076196 Creamer 200 cc.



### Deep Dish

1020310 Deep Dish 10 cm. 90 cc.



### Spoon

1026400 Spoon 13 cm.

# 2738 BAND OF PLATINUM

## ITEM RANGE

PATRA



### PLATE

- 1061027 Plate 27 cm.
- 1061023 Plate 23.5 cm.
- 1061020 Plate 20.5 cm.
- 1061016 Plate 16.5 cm.



### SOUP PLATE

- 1061223 Soup Plate 23 cm.



### OVAL PLATE

- 1064086 Oval Plate 36 cm.
- 1064078 Oval Plate 28 cm.
- 1064073 Oval Plate 23 cm.



### DISH

- 1020310 Deep Dish 10 cm.
- 1026555 3-Compartment Sauce Dish 14 cm.
- 1026554 Round Divided Dish 10 cm.
- 1026553 Square Divided Dish 9 cm.



### BOWL

- 1023070 Deep Bowl 20 cm.
- 1023067 Deep Bowl 17.5 cm.



- 1061318 Salad Bowl 18 cm.
- 1061316 Salad Bowl 16 cm.



- 1023012 Noodle Bowl 12.5 cm.
- 1023011 Rice Bowl 11.5 cm.
- 1023009 Shark's Fin Soup Bowl 9.5 cm.



### ACCESSORY

- 1026400 Spoon 13 cm.
- 1016401 Coffee Spoon 12.5 cm.
- 1026551 Chopsticks Rest 6 cm.
- 1806592 Spoon Rest 9 cm.
- 1016502 Salt & Pepper Set
  - 1016500 Salt (1 Hole)
  - 1016501 Pepper (4 Holes)



### TEAPOT

- 1076032 Teapot 800 cc. with Lid
  - 1076030 Teapot 800 cc. Body
  - 1076031 Teapot Lid



### CUP & SAUCER

- 1072057 Teacup & Saucer 200 cc.
  - 1072055 Teacup 200 cc.
  - 1072006 Saucer 15 cm.



- 1022893 Chappai Cup Set
  - 1022890 Chappai Cup 190 cc.
  - 1022892 Chappai Lid
  - 1022891 Saucer (Round Dish 10 cm.)



### SUGAR & CREAMER

- 1076178 Sugar Bowl 250 cc. with Lid
  - 1076176 Sugar Bowl 250 cc. Body
  - 1076177 Sugar Bowl Lid
- 1076196 Creamer 200 cc.





# M965 CANYON

## ITEM RANGE

PATRA



### Coupe Plate

1020131 Coupe Plate 31 cm.  
1020126 Coupe Plate 26.5 cm.



### Coupe Plate

1020123 Coupe Plate 23 cm.  
1020116 Coupe Plate 16.5 cm.



### Rectangular Plate

1034926 Rectangular Plate 26.5 cm.  
1034921 Rectangular Plate 21.5 cm.



### Soup / Cereal Bowl

1061320 Soup / Cereal Bowl 20 cm. 800 cc.



### Bowl

1023020 Bowl 20 cm. 1,260 cc.  
1023017 Bowl 17.5 cm. 890 cc.  
1023062 Bowl 12.5 cm. 340 cc.



### Tea / Coffee Pot with Lid 1016012

1016010 Tea / Coffee Pot 700 cc.  
1016011 Tea / Coffee Pot Lid



### Tea / Coffee Cup & Saucer 1132013

1132010 Tea / Coffee Cup 210 cc.  
1072006 Saucer 15.5 cm.

# M873 CHLOÉ

## ITEM RANGE



### PLATE

1061027 Plate 27 cm.

1061023 Plate 23.5 cm.

1061020 Plate 20.5 cm.

1061016 Plate 16.5 cm.



### DEEP PLATE

1061223 Deep Plate 23 cm.



### OVAL PLATE

1064081 Oval Plate 31 cm.

1064076 Oval Plate 26 cm.



### DEEP DISH

1120310 Deep Dish 10 cm.



### SPOON

1026400 Spoon 13 cm.



### BOWL

1023017 Bowl 17 cm.

1023012 Rice Bowl 12.5 cm.

1023010 Bowl 10.5 cm.



1023073 Deep Bowl 23 cm.

1023070 Deep Bowl 20 cm.

1023067 Deep Bowl 17.5 cm.



### CASSEROLE

1082909 Casserole 2,500 cc. with Lid

1082904 Casserole 2,500 cc. Body

1082907 Casserole 2,500 cc. Lid



### SALT & PEPPER

1086504 Salt (1 Hole)

1086505 Pepper (4 Holes)



# PATRA



### TEAPOT

1086022 Teapot 1,000 cc. with Lid

1086020 Teapot 1,000 cc. Body

1086021 Teapot 1,000 cc. Lid



### CUP & SAUCER

1082082 Tea/ Coffee Cup & Saucer 220 cc.

1082080 Tea/ Coffee Cup 220 cc.

1072006 Saucer 15 cm.



### CREAMER

1086182 Creamer 140 cc.



# M740 FLORAL BLUE & WHITE

## ITEM RANGE



### PLATE

1121030 Plate 30 cm.



1121027 Plate 27 cm.



1121024 Plate 24 cm.



1121020 Plate 20 cm.



1121017 Plate 17 cm.



### DEEP PLATE

1121222 Deep Plate 22 cm.



### OVAL PLATE

1124135 Oval Plate 35 cm.



1124128 Oval Plate 28 cm.



1124123 Oval Plate 23 cm.



### DEEP DISH

1120310 Deep Dish 10 cm.



### BOWL

1023011 Bowl 11.5 cm.



1123017 Bowl 17 cm.



1123035 Bowl 15 cm.



1123043 Bowl 23 cm.



### CASSEROLE

1122937 Casserole 2,800 cc. with Lid

1122936 Casserole 2,800 cc. Lid

1122931 Casserole 2,800 cc. Body



### TEA/COFFEE POT

1126022 Teapot 800 cc. with Lid

1126036 Teapot 800 cc. Lid

1126025 Teapot 800 cc. Body



1122022 Cup & Saucer 170 cc.

1122020 Cup 170 cc.

1122021 Saucer 13 cm.



1122032 Cup & Saucer 230 cc.

1122030 Cup 230 cc.

1122031 Saucer 15 cm.



### SUGAR & CREAMER

1126167 Sugar Bowl with Lid

1126166 Sugar Bowl Lid

1126163 Sugar Bowl Body



1126187 Creamer 230 cc.

BD9E  
FLORENTINA CREAM GOLD  
ITEM RANGE

PATRA

PLATE

- 1061032 Plate 32 cm.
- 1061027 Plate 27 cm.
- 1061023 Plate 23.5 cm.
- 1061020 Plate 20.5 cm.
- 1061016 Plate 16.5 cm.

SOUP PLATE

- 1061223 Soup Plate 23 cm.
- 1061221 Soup Plate 20.5 cm.

OVAL PLATE

- 1064086 Oval Plate 36 cm.
- 1064078 Oval Plate 28 cm.
- 1064073 Oval Plate 23 cm.

DEEP DISH

- 1020310 Deep Dish 10 cm.

BOWL

- 1023015 Bowl 15 cm.
- 1023012 Rice Bowl 12.5 cm.
- 1023011 Bowl 11.5 cm.
- 1183023 Bowl 23 cm.
- 1023070 Deep Bowl 20 cm.
- 1023067 Deep Bowl 17.5 cm.
- 1061318 Salad Bowl 18 cm.
- 1061316 Salad Bowl 16.5 cm.

TEAPOT

- 1076032 Teapot 800 cc. with Lid
- 1076030 Teapot 800 cc. Body
- 1076031 Teapot 800 cc. Lid

CUP & SAUCER

- 1082082 Tea/ Coffee Cup & Saucer 220 cc.
- 1082080 Tea/ Coffee Cup 220 cc.
- 1072006 Saucer 15 cm.

SUGAR & CREAMER

- 1076178 Sugar Bowl 250 cc. with Lid
- 1076176 Sugar Bowl 250 cc. Body
- 1076177 Sugar Bowl Lid
- 1076196 Creamer 200 cc.

MUG

- 1062401 Mug 300 cc.

SPOON

- 1026400 Spoon 13 cm.



# M996 FOLIAGE

ITEM RANGE

PATRA



## RIM PLATE



- 1061032 Pizza Plate 32 cm.
- 1061016 Rim Plate 16.5 cm.



## BOWL

- 1023017 Bowl 17.5 cm.
- 1023012 Noodle Bowl 12.5 cm.



## MUG

- 1802412 Mug 450 cc.

## TEA/COFFEE POT

- 1086022 Teapot 1,000 cc, with Lid
  - 1086021 Teapot Lid
  - 1086020 Teapot 1,000 cc. Body



## DISH



- 1020310 Deep Dish 10 cm.

## SOUP PLATE



- 1061223 Soup Plate 23 cm.



## CUP & SAUCER

- 1062047 Tea/ Coffee Cup & Saucer 250 cc.
  - 1062045 Tea/ Coffee Cup 250 cc.
  - 1062041 Saucer 15 cm.

# N001 GRACIOUS

ITEM RANGE

PATRA



## RIM PLATE

- 1061032 Pizza Plate 32 cm.
- 1061016 Rim Plate 16.5 cm.



## BOWL

- 1023017 Bowl 17.5 cm.
- 1023012 Noodle Bowl 12.5 cm.



## MUG

- 1802412 Mug 450 cc.



- 1061027 Rim Plate 27 cm.
- 1061023 Rim Plate 23.5 cm.



## TEA/COFFEE POT

- 1086022 Teapot 1,000 cc. with Lid
  - 1086021 Teapot Lid
  - 1086020 Teapot 1,000 cc. Body



## DISH

- 1020310 Deep Dish 10 cm.



## SOUP PLATE

- 1061223 Soup Plate 23 cm.



## CUP & SAUCER

- 1062047 Tea/Coffee Cup & Saucer 250 cc.
  - 1062045 Tea/Coffee Cup 250 cc.
  - 1062041 Saucer 15 cm.



# 816A HAVANA BLUE

## ITEM RANGE



PATRA



### COUPE PLATE

- 1020131 Coupe Plate 31 cm.
- 1020126 Coupe Plate 26.5 cm.
- 1020121 Coupe Plate 21 cm.
- 1020116 Coupe Plate 16.5 cm.



### RIM PLATE

- 1061027 Plate 27 cm.



### RECTANGULAR PLATE

- 1034926 Rectangulare Plate 26.5 cm.
- 1034921 Rectangulare Plate 21.5 cm.



### BOWL

- 1010320 Coupe Soup 20.5 cm.



- 1010317 Cereal/ Salad Bowl 17 cm.



- 1023023 Bowl 23 cm.
- 1023017 Bowl 17 cm.
- 1023015 Bowl 15 cm.



- 1023012 Bowl 12.5 cm.
- 1023011 Bowl 11 cm.



### TEA/COFFEE POT

- 1026014 Teapot 700 cc. with Lid
  - 1016011 Teapot Lid
  - 1026013 Teapot 700 cc. Body



- 1122122 Coffee Cup & Saucer 100 cc.

- 1122020 Cup 170 cc.
- 1122021 Saucer 13 cm.



- 1122012 Coffee Cup & Saucer 210 cc.

- 1122030 Cup 230 cc.
- 1122031 Saucer 15 cm.



### SUGAR & CREAMER

- 1016172 Sugar Bowl with Lid 230 cc.
  - 1016171 Sugar Bowl Lid
  - 1016170 Sugar Bowl 230 cc. Body



- 1016192 Creamer 150 cc.



### CASSEROLE

- 1022922 Casserole 2.000 cc. with Lid
  - 1022921 Casserole 2.000 cc. Lid
  - 1022920 Casserole 2.000 cc. Body



### DEEP DISH

- 1020310 Deep Dish 10 cm.



### SPOON

- 1026400 Spoon 13 cm.

# M392 NANCY

## ITEM RANGE



### Plate

1061032 Pizza Plate 32 cm.  
1061027 Plate 27 cm.



### Plate

1061023 Plate 23 cm.  
1061020 Plate 20.5 cm.  
1061016 Plate 16 cm.



### Soup Plate

1061223 Soup Plate 23 cm.



### Oval Plate

1064076 Oval Plate 26 cm.  
1064081 Oval Plate 31 cm.  
1064086 Oval Plate 36 cm.



### Bowl

1023017 Bowl 17 cm.



### Bowl

1023012 Bowl 12.5 cm.  
1023010 Bowl 10.5 cm.



### Deep Bowl

1023073 Deep Bowl 23 cm.  
1023070 Deep Bowl 20 cm.  
1023067 Deep Bowl 17.5 cm.



### Casserole Set 1082909

1082904 Casserole 2,500 cc.  
1082907 Casserole Lid



### Tea / Coffee Cup & Saucer 1082082

1082080 Tea / Coffee Cup 220 cc.  
1072006 Saucer 15 cm.



### Tea Pot Set 1086022

1086020 Tea Pot 1000 cc.  
1086021 Tea Pot Lid

### Creamer

1086182 Creamer 140 cc.



### Deep Plate

1020310 Deep Plate 10 cm.



### Spoon

1024600 Spoon 13 cm.



### Salt & Peper Set 1086545

1086504 Salt (1 Hole)  
1086505 Pepper (4 Holes)



# M874 VIDA

## ITEM RANGE



### Plate

1061032 Plate 32 cm.  
1061027 Plate 27 cm.  
1061023 Plate 23 cm.  
1061020 Plate 20.5 cm.  
1061016 Plate 16 cm.



### Oval Plate

1064086 Oval Plate 36 cm.  
1064081 Oval Plate 31 cm.  
1064078 Oval Plate 28 cm.  
1064076 Oval Plate 26 cm.



### Soup Plate

1061223 Soup Plate 23 cm.  
1061221 Soup Plate 20.5 cm.



### Deep Bowl

1023012 Deep Bowl 12.5 cm.  
1023010 Deep Bowl 10.5 cm.



### Deep Bowl

1023017 Deep Bowl 17 cm.



### Deep Bowl

1023073 Deep Bowl 23 cm.  
1023070 Deep Bowl 20 cm.  
1023067 Deep Bowl 17.5 cm.



PATRA



### Tea/ Coffee Cup & Saucer 1082082

1082080 Tea/ Coffee Cup 220 cc.  
1072006 Saucer 15 cm.

### Tea Pot with Lid 1086022

1086020 Tea Pot 1,000 cc.  
1086021 Tea Pot Lid

### Creamer

1086182 Creamer 160 cc.



### Casserole Set 1082909

1082904 Casserole 2,500 cc.  
1082907 Casserole Lid



### Deep Plate

1020310 Deep Plate 10 cm.



### Spoon

1026400 Spoon 13 cm.



### Salt & Pepper 1086545

1086504 Salt (1 Hole)  
1086505 Pepper (4 Holes)



# BM7A, BM7B : WOOD THAI

## ITEM RANGE

PATRA



### Rim Plate

1121030 Platter 30 cm. BM7A

1121027 Rim Plate 27 cm. BM7A



### Rim Plate

1121024 Rim Plate 24 cm. BM7A

1121017 Rim Plate 17 cm. BM7A



### Soup Plate

1121222 Soup Plate 22 cm. BM7A



### Oval Platter

1124135 Oval Platter 35 cm. BM7A

1124128 Oval Platter 28 cm. BM7A



### Bowl

1123043 Bowl 23 cm. BM7A

1123017 Bowl 17.5 cm. BM7A

1123035 Cereal Bowl 15.5 cm. BM7A



### Noodle Bowl

1023012 Noodle bowl 12.5 cm. BM7A



### Casserole 2,800 cc. with Lid 1122937

1122931 Casserole 2,800 cc. BM7A

1122936 Casserole Lid BM7A



### Sugar 230 cc. with Lid 1126167

1126163 Sugar 230 cc. BM7A

1126166 Sugar Lid 230 cc. BM7A

### Creamer 230 cc.

1126187 Creamer 230 cc. BM7A



### Coffee Cup & Saucer 1122032

1122030 Coffee Cup 220 cc. BM7B

1122031 Saucer 15 cm. BM7A